

Processing Guide Secondary Insulation

PG-129 – Vacuum Pressure Impregnating (VPI) Unsaturated Epoxy Copolymer



## Processing Guide PG - 129 Vacuum Pressure Impregnating (VPI) Unsaturated Epoxy Copolymer Process

Process Step	Optimum	Minimum	Comments
Preheat	1 hour at 135 - 150°C(275 - 300°F) Once unit reaches temperature	None	Relax magnet wire, drives out moisture, thermosets tapes, assists in penetration
Dry Vacuum	2 hours at 29-30 inches of Hg *see below	1 hour at 27 inches of Hg	Removes air to allow penetration of resin.
Part Temperature when resin is introduced	38 – 43°C (100 - 110°F)	25 – 43°C (77°F – 110°F)	Temperature has a direct bearing on resin penetration. If too low resin will not penetrate fully. If too high resin can be damaged
Wet vacuum	None	None	Pressure should be applied as soon as possible to assist with resin penetration.
Gas to release vacuum	Nitrogen	Dry Air	Nitrogen is recommended to release vacuum and pressurize tank to insure safest operation
Pressure	2 hours 80-90 psi for coils with minimal taping. Add one hour for each layer of tape.	1 hour at 80 psi for coils with minimal taping. Add one hour for each layer of tape.	A short pressure cycle could reduce penetration.
Drain Time	15-30 minutes	10-15 minutes	Longer drain will re- capture more resin.
Cool Resin	Agitate to 18-25°C (65-77°F)	Agitate to 25-27°C (75 - 80°F)	Return to holding tank keeping material cool improves tank life
Bake Schedule	As recommended by product data sheet.	As recommended by product data sheet.	Full cure is required to develop all performance properties.

<sup>\*</sup>Turn off Vacuum pump, close vacuum valve to minimize monomer loss.

Please contact ELANTAS PDG, Inc. Technical Service if you have any questions.

Phone number 1.314.621.5700 Extension 717 or 1.800.325.7492 Extension 717

The above properties are typical values and are not intended for specification use.